

Installation Instructions

These instructions apply to Allied Moulded Products part numbers FB-BRPLG, FB-NPLG

This cover plug replacement kit is to be used with Allied Moulded part numbers FB-1, FB-1N, FB-2, FB-2N, FB-3, FB-3N

1. Remove the old cover plug from the installed floor box assembly, if necessary
2. Install the new cover plug by screwing the plug into the cover. Note that the plug may not sit flush to the cover in the tightened position.

